

# Wireless Physical Layer Concepts: Part II

Raj Jain  
Professor of CSE  
Washington University in Saint Louis  
Saint Louis, MO 63130  
Jain@cse.wustl.edu


These slides are available on-line at:  
<http://www.cse.wustl.edu/~jain/cse574-08/>



- Channel Model
- Path Loss, Fading, Shadowing, Noise
- $d^{-4}$  Power Law
- Fresnel Zones
- Tapped Delay Line Model
- Doppler Spread


## Wireless Radio Channel

- ❑ Path loss: Depends upon distance and frequency
- ❑ Noise
- ❑ Shadowing: Obstructions
- ❑ Frequency Dispersion (Doppler Spread) due to motion
- ❑ Interference
- ❑ Multipath: Multiple reflected waves
- ❑ Inter-symbol interference (ISI) due to dispersion



4-3

## Channel Model



- ❑ Power profile of the received signal can be obtained by *convolving* the power profile of the transmitted signal with the impulse response of the channel.
- ❑ Convolution in time = multiplication in frequency
- ❑ Signal  $x$ , after propagation through the channel  $H$  becomes  $y$ :
$$y(f) = H(f)x(f) + n(f)$$
- ❑ Here  $H(f)$  is **channel response**, and  $n(f)$  is the noise. Note that  $x$ ,  $y$ ,  $H$ , and  $n$  are all functions of the signal frequency  $f$ .

Washington University in St. Louis

CSE574S

©2008 Raj Jain

4-4

## Path Loss

- ❑ Power is distributed equally to spherical area  $4\pi d^2$
- ❑ The received power depends upon the wavelength
- ❑ If the Receiver collects power from area  $A_R$ :

$$P_R = P_T G_T \frac{1}{4\pi d^2} A_R$$

- ❑ Receiving Antenna Gain

$$G_R = \frac{4\pi}{\lambda^2} A_R$$

$$P_R = P_T G_T G_R \left(\frac{\lambda}{4\pi d}\right)^2$$

- ❑ This is known as Frii's Law.  
Attenuation in free space increases with frequency.

## Path Loss (Cont)

- ❑ In practice the distance exponent is higher:  
3.5 to 5.5 (after a breakpoint)

$$P_R = P_R(d_{\text{break}}) \left(\frac{d}{d_{\text{break}}}\right)^{-n}$$


➤  $n \approx 3.5$  to  $5.5$

- ❑ In log scale:

$$P_R(d = 1m) = P_T + G_T + G_R + 20 \log_{10} \left(\frac{\lambda}{4\pi}\right)$$

$$P_R(d) = P_R(1) - 20 \log_{10} d$$

## **d<sup>-4</sup> Power Law**



- Using a two-ray model

$$P_R = P_T G_T G_R \left( \frac{h_t h_r}{d^2} \right)^2$$


- Here,  $h_T$  and  $h_R$  are heights of transmit and receive antennas
- It is valid for distances larger than

$$d_{\text{break}} = 4h_T h_R / \lambda$$

- Note that the received power becomes independent of the frequency.
- Measured results show  $n=1.5$  to  $5.5$


## **d<sup>-4</sup> Power Law (Cont)**

- The transition happens around 100m




## Small Scale Fading

- The signal amplitude can change by moving a few inches  $\Rightarrow$  Small scale fading



## Large Scale Fading

- Shadowing gives rise to large scale fading




## Shadowing

$$PL(d) \text{ dB} = \overline{PL}(d_0) + 10\alpha \log\left(\frac{d}{d_0}\right) + \chi$$

- $\chi$  is a Gaussian random variable with standard deviation  $\sigma^2$
- Power received at the same distance may be random and has log normal distribution
- Log Normal Shadowing

## Path Loss




## Noise


Noise consists of 3 components:

1. Thermal Noise: Proportional to absolute temperature
  - Noise Power Spectral Density  $N_0 = k_B T$
  - Where,  $k_B$  = Boltzman's constant =  $1.38 \times 10^{-23}$  Joules/Kelvin
  - For a band of width B:
    - Noise Power  $P_n = N_0 B = -174 + 10 \log_{10}(B)$  dBm at 300°K
2. Spurious Emissions: Car ignition and Electronic devices  
Decreases at higher frequencies. More noise in urban areas.
3. Receiver Noise: Amplifiers and mixers add noise.
  - Noise generated before the amplifiers also gets amplified

## Interference Limited Systems



## Fresnel Zones




- Draw an ellipsoid with BS and MS as Foci
- All points on ellipsoid have the same BS-MS run length
- Fresnel ellipsoids = Ellipsoids for which run length =  $L_{oS} + i\lambda/2$
- At the Fresnel ellipsoids results in a phase shift of  $i\pi$
- Radius of the  $i$ th ellipsoid at distance  $d_T$  from the transmitter and  $d_R$  from the receiver is  $\sqrt{\frac{i\lambda d_T d_R}{d_T + d_R}}$
- Free space ( $d^2$ ) law is followed up to the distance at which the first Fresnel Ellipsoid touches the ground

## Link Budget


Transmitted Power $P_T = 30W$	= 45 dBm
Cable Loss	= -5 dB
Antenna Gain $G_T$	10 dB
<hr/>	
EIRP (Equivalent Isotropically Radiated Power)	50 dBm
Receiver Sensitivity	-102 dBm
Fade Margin	12 dB
Minimum Received Power	-90 dBm
Allowable Path Loss	140 dB
Path loss at $d_{break} = 100m \frac{\lambda}{4\pi d^2}$	72 dB
Path loss beyond breakpoint $(d/100)^{-n}$	68 dB
Coverage distance $100 \times 10^{6.8/n}$	8.8 km if $n=3.5$

## Multipath Power Delay Profile



- A single impulse results in multiple impulses at different times
- Delay Spread = Maximum delay after which the received signal becomes negligible =  $\tau_{\max}$ .

## Tapped Delay Line Model



$$h(t, \tau) = \sum_{i=1}^N c_i(t) \delta(\tau - \tau_i)$$

- Coherence Time = Time for which channel remains same
- Coherence Bandwidth = Bandwidth for which channel remains same

## Doppler Spread

- ❑ Power Delay Profile of Channel = Power distribution over time for an impulse signal
- ❑ Doppler Power Spectrum = Power Distribution over frequency for a signal transmitted at one frequency
- ❑ Non-zero for  $(f-f_D$  to  $f+f_D)$
- ❑ Doppler spread =  $f_D$
- ❑ Coherence Time =  $1/\text{Doppler Spread}$
- ❑ If the transmitter, receiver, or intermediate objects move very fast, the doppler spread is large and coherence time is small

## Typical Doppler Spread

Carrier Freq	Speed	Max Doppler Spread	Coherence Time
2.5 GHz	2 km/hr	4.6 Hz	200 ms
2.5 GHz	45 km/hr	104.2 Hz	10 ms
2.5 GHz	100 km/hr	231.5 Hz	4 ms
5.8 GHz	2 km/hr	10.7 Hz	93 ms
5.8 GHz	45 km/hr	241.7 Hz	4 ms
5.8 GHz	100 km/hr	537 Hz	2 ms

## Summary



- ❑ Path loss increase at a power of 2 to 5.5 with distance.
- ❑ Fading = Changes in power changes in position
- ❑ Fresnel zones = Ellipsoid with distance of  $LoS + i\lambda/2$   
Any obstruction of the first zone will increase path loss
- ❑ Coherence time = Time for which channel remains same
- ❑ Doppler Spread = Frequency Band over which channel remains same

## Homework 4

- ❑ Determine the mean received power at a SS. The channel between a base station at 14 m and the subscriber stations at 4m at a distance of 500m. The Transmitter and Reciver antenna gains are 10dB and 5 dB respectively. Use a power exponent of 4. Transmitted power is 30 dBm.